

## SIDE GUTTER INSTALLATION INSTRUCTIONS

1. Remove cover from opening in side of CT cabinet where gutter is to be attached. Do not discard cover or mounting hardware.

\*\*\* If the side gutter is ordered separately from the CT cabinet - see note below \*\*\*

2. Locate line of small knockouts approximately 1 foot from lower edge of side of CT enclosure. Open knockouts.
3. Position straight ungasketed aluminum spacer at line of knockouts. Thread mounting screws into spacer through holes in enclosure. Screws will protrude through spacer when properly tightened.
4. Inspect gasketing on aluminum spacer pieces to insure that it is intact. If gasket is damaged, consult factory for replacement.
5. Position gasketed spacer pieces at the enclosure side opening. Use pieces with machined ends at top and bottom of opening. Use unmodified pieces at sides of opening.
6. Thread mounting screws through holes in enclosure into spacer pieces. Screws will protrude through spacer when properly tightened. Tighten screws sufficiently to compress gasket.
7. Position side gutter next to CT enclosure. Securing holes in gutter will line up with screws protruding through spacers.
8. Attach washers and nuts to screws and tighten to compress gasket around opening. Attach washers and nuts to screws at lower spacer and tighten.
9. Install cover removed in step 1 over unused opening in gutter.

