



**INSTRUCTIONS FOR INSTALLATION OF USRL UNIT**

1. PLACE TEMPLATE INSIDE BOTTOM OF TRANSOCKET WITH BACK OF TEMPLATE AGAINST BACK OF TRANSOCKET.
2. MARK CENTER LOCATIONS OF 3/8" DIA. HOLES AND CORNERS OF CENTER RECTANGULAR OPENING.
3. DRILL FOUR 3/8" DIA. HOLES AND CUT OUT RECTANGULAR OPENING.
4. MOUNT USRL TO TRANSOCKET WITH FOUR 1/4-20 BOLTS AND NUTS.

(MUST PRINT ON 11 X 17 PAPER FOR ACCURATE SCALE)