



INSTRUCTIONS FOR INSTALLATION OF USR UNIT.

1. PLACE TEMPLATE INSIDE BOTTOM OF TRANSOCKET WITH BACK OF TEMPLATE AGAINST BACK OF TRANSOCKET.
2. MARK CENTER LOCATIONS OF 3/8" DIA. HOLES AND 4" ELECTRICAL KNOCK OUTS
3. DRILL FOUR 3/8" DIA. HOLES, PULL TWO 4" KNOCK OUTS, SAW BETWEEN KNOCK OUTS.
4. MOUNT USR TO TRANSOCKET WITH FOUR 1/4-20 BOLTS AND NUTS.